

PRODUCT DATA SHEET

TIMBER Protect SK

TIMBER Protect SK is a combination of fleece coated with an impermeable membrane on both sides and a specially matched polyacrylic adhesive. The tear-resistant synthetic liner facilitates handling. Construction elements can be bonded together over the entire surface with the wide sheets as protection during transport and the construction period. Joins between sheets can easily be made lengthwise along the marking grid and diagonally with 10 cm overlap.

FIELD OF APPLICATION

- protection for construction elements of solid wood and wooden composite materials during transport
- protection against the elements
- intermediate floors and walls
- also for use as permanent airtight layer on CLT

ADVANTAGES

- all-over self-adhesive
- transparent
- double-function membrane
- variable diffusion
- optimized re-drying of residual moisture in construction elements
- non-slip safety: anti-slip coating
- no fleece abrasion
- practical grid pattern for overlap measurement
- low heat absorption due to protection of material through light colouring
- very good self-adhesion

RECOMMENDED PRODUCTS

-  AIRSTOP ROLL Pressing Roller
-  UNI MS Sealant Adhesive
-  OMEGA PLASTO Tape

AVAILABLE IN THE FOLLOWING DIMENSIONS

Roll width	1,5 m
Roll length	50 m
Split liner	250/1250

PRODUCT DATA

Material composition	PP fleece with double special membrane and anti-slip coating, special acrylic adhesive	
Thickness	0,33 mm	
Weight	215 g/m ² (±10%)	
sd-value	0,28 - 2,68 m	
Temperature resistance	-40 °C - 70 °C	
Resistance to water flow EN 1928	W1	
Working temperature	-5 °C - 40 °C	
Expandability EN 12311-1	 > 30 %	 > 30 %
Tensile strength EN 12311 - 1	 >200 N/50mm	 >200 N/50mm
Tear propagation resistance EN 12310-1	 > 50 N	 > 50 N
Storage	Cool and dry	
UV-resistance uncovered	12 weeks	
Fire performance EN 13501_1 / EN 11925_2	E	

TIMBER Protect SK



ADHESIVE PROPERTIES

TIMBER Protect SK adopts the functions of wind and air-tightness as well as weather protection, not however the function of a load-bearing connection. Timber Protect SK cannot be plastered or painted over.

ADHESIVE TECHNIQUE

TIMBER Protect SK must be bonded with the substrate over the entire surface. We recommend first cutting the required quantity to length, pulling the liner away a little and attaching the TIMBER Protect SK at one end of the construction component.

The second step is to gradually pull off the liner on both sides, at the same time rubbing on the sheeting to keep it bubble-free, using e.g. a wide squeegee or wide, straight brush. The liner can be wound around a square timber and then pulled off. In this way the tension used when pulling can be evenly distributed and a crease-free and smooth bond is achieved. Overlaps of the adhesive tape should be min. 10 cm. Sufficient pressure must be applied to the open edge using a pressure roller.



ADHESION ON THE FOLLOWING SUBSTRATES

Wood, wooden composite boards (OSB, MDF, 3S-boards, chipboard, plywood...), synthetics, metal free from oxidation and rust, masonry, unsanded concrete.

The materials used must be free from dust, grease and silicone, the substrates must also be dry and stable. For rough wood, similar uneven substrates, and at low temperatures, we recommend pre-treatment of the substrate with one of ISOCELL's primers.

Please note that at low temperatures, and even at slight temperature changes, surface condensation may occur. This has the effect of a release layer and reduces adhesion. After applying the construction waterproofing a curing process takes place. Depending on the temperature this can take 6 – 24 hours. Only then is complete adhesion achieved.

TIPS

Walls: observe direction of water-flow. Always begin with adhesion at the bottom. Avoid open edges. Fold down at top.

Intermediate floors: use a pressure roller in the region of edges of overlaps. If there is creasing at the edge or damage to the TIMBER Protect SK we recommend the use of AIRSTOP PLASTO Tape as repair tape. If available UNI MS Sealant Adhesive can also be used for repair work.

Use in combination with UNI Primer Spray in the edge and overlap regions permits low working temperatures to -10° on a substrate free from ice and, when sufficient pressure is applied, increases reliability under extreme weather conditions.

ISOCELL GmbH & Co KG

Gewerbestraße 9
5202 NEUMARKT AM WALLERSEE | Österreich
Tel.: +43 6216 4108
office@isocell.at

ISOCELL SCHWEIZ AG

Herbergstrasse 29
9524 ZUZWIL | Suisse /Schweiz
Tel.: +41 71 940 06 72
office@isocell.ch

ISOCELL FRANCE

170 Rue Jean Monnet | ZAC de Prat Pip Sud
29490 GUIPAVAS | France
Tél.: +33 2 98 42 11 00
contact@isocell-france.fr

ISOCELL BUREEL BELGIË

Außenborner Weg 1 | Schoppen
4770 AMEL | Belgique
Tel.: +32 80 39 90 58
office@isocell.be

ISOCELL Sverige AB

Torshamnsgatan 35
164 40 KISTA | Sverige
Tel.: +46 10 130 25 00
info@isocell.se

ISOCELL
www.isocell.com